

ZIGVIEW eyepiece adapter compatibility

July, 2005

■ Nikon

Eye piece adapter		Type	Cameras	Remark
N	Released	Rectangle	D100, D70, D70s, D50, F80, F50, F55, F60, F65, F70, F75, F301, F401, F501, F601, PRONEA, etc	Non-rotation
N1	Released	Rectangle	D100, D70, D70s, D50, F80, F50, F55, F60, F65, F70, F75, F301, F401, F501, F601, PRONEA, etc	
N2	July, 2005	Circle	FM2, FM, FE, FA, EM, FM10, FM3A, EL, EL2, etc	
N3	Released	Circle	D1, D2, D2H, D2X, F801, F90, F100, F3, F4, F5, F6	

■ Fuji

Eye piece adapter		Type	Cameras	Remark
N	Released	Rectangle	S1pro, S2pro, S3pro	Non-rotation
N1	Released	Rectangle	S1pro, S2pro, S3pro	

■ Canon

Eye piece adapter		Type	Cameras	Remark
C	Released	Rectangle	300D, 350D, 10D, 20D, 1D, 1D MK II, EOS 66, 888, 100, 100s, 500N, etc	Non-rotation
C1	Released	Rectangle	300D, 350D, 10D, 20D, 1D, 1D MK II, EOS 66, 888, 100, 100s, 500N, etc	Canon Ec-C type
C2	Not planned	Rectangle	EOS 3, 5, 55, etc	Canon Ed-C type

■ Minolta (Konica Minolta)

Eye piece adapter		Type	Cameras	Remark
M	Released	Rectangle	Alpa 9, 7D, etc	Almost all model

■ Pentax

Eye piece adapter		Type	Cameras	Remark
P	Released	Rectangle	ist, istD, istDs, ME, ME super, MZ, etc	Almost all model

■ Sigma

Eye piece adapter		Type	Cameras	Remark
S	Released	Rectangle	SD9, SD10, etc	

■ Olympus

Eye piece adapter		Type	Cameras	Remark
O	Not planned	Rectangle	E-300	
O(O2)	Not planned	Circle	E1	